

**V
O
L
U
M
E
C
H
A
N
G
E
S**

There are several reasons that concrete changes in volume. Understanding the nature of these changes is useful for all those who design, specify, and work with concrete.

Concrete, like other construction materials, contracts and expands with changes in moisture and temperature, and deflects in response to loading. In addition, concrete begins to change volume as soon as the residual moisture from its initial mixing begins to leave. Concrete that is not cured will begin to lose moisture, and change volume very early in its life.

There are two types of shrinkage commonly associated with concrete: plastic shrinkage and drying shrinkage. Plastic shrinkage often resembles tears in the surface and results from a combination of chemical shrinkage and rapid evaporation of moisture from the surface. Plastic shrinkage cracking can be controlled by the use of spray-on evaporation retarders, or by minimizing surface evaporation through use of plastic sheeting, fogging, wet burlap, wind breaks, or shading.

Drying shrinkage is the volume change in hardened concrete due to moisture loss. As this drying takes place, concrete shrinks. Where there is no restraint, movement occurs freely and no cracks develop. When there is restraint, and when the tensile stress from restrained drying shrinkage exceeds the tensile strength of concrete, cracks develop. Random cracks may develop if joints are not properly provided. Concrete joints for slabs on the ground should be spaced at distances 24 to 36 times the slab thickness to control random cracks. A 4" thick slab should have a maximum joint spacing of 12 feet ($4" \times 36 = 144" \div 12" = 12$ feet). **The most important factor affecting drying shrinkage is the paste content of the concrete when placed.** This explains why higher compressive strength concrete mixes have increased shrinkage and cracking.

Curling, or warping, of concrete slabs is a phenomenon that occurs from differences in moisture or temperature between the top and bottom of a slab. When a newly constructed building is enclosed, the relative humidity decreases and the shrinkage gradient increases. Curling will begin and continue until the moisture differences between the top and bottom of the concrete slab, and within the concrete section, cease.

Follow these steps to help minimize the harmful effects of volume changes:

- Design and use a concrete mix with the lowest paste content that is needed for strength, durability, and workability.
- Specify and use the lowest compressive strength concrete that is required.
- Do not specify a water / cementitious ratio lower than needed for exposure and durability requirements.
- Do not add water to make concrete easier to place or finish. Admixtures can provide increased workability without increasing the paste content of concrete.
- Use a surface evaporation retarder whenever there is a possibility of plastic shrinkage cracking.
- Cure the concrete to maintain its moisture for as long as possible. Wet curing is the best method.
- Provide joints that are properly spaced and deep enough to minimize and control cracking.



Drying Shrinkage Cracking



Plastic Shrinkage Cracking

of Concrete

References:

PCA – Design and Control of Concrete Mixtures, Fourteenth Edition, Skokie, IL

NRMCA CIP 4 – Cracking Concrete Surfaces, NRMCA, Silver Spring, MD

Concrete International – Why Slabs Curl, Skokie, IL

The Concrete Producer - Controlling Shrinkage, Rosemont, IL

PACA – Things to Know About Curing & Sealing Concrete, Harrisburg, PA

Brought to you

by:



Pennsylvania Aggregates and Concrete Association

Pennsylvania Aggregates and Concrete Association

3509 North Front Street, Harrisburg, PA 17110

Ph: 717-234-2603

Fax: 717-234-7030

Web: www.pacaweb.org

www.specifyconcrete.org

www.rcc4pa.org

Disclaimer: Pennsylvania Aggregates and Concrete Association is a trade association (“Association”) organized under the Pennsylvania Nonprofit Corporation Law. The information provided here is intended solely for the continuing education of **Qualified Professionals** who are competent to evaluate the significance and limitations of the information provided and who accept total responsibility and liability for the accuracy of any application of the information contained in this publication. **Others should obtain assistance from a Qualified Professional before proceeding.** The Association and its members make no express or implied warranty with respect to the information contained herein or the accuracy thereof. They disclaim any product liability in connection with the publication or any information contained herein. The information is garnered from various publications reflecting current industry recommendations.